

SIZE GUIDE - MX BOOT

Compare the measurement (in cm) of the longest part of the foot using the table below:
 cross reference this value against the "SHOE INSIDE LENGTH".
 Then, from this column, check whether the measured length of the foot is greater than the value of the corresponding "COMFORT SIZE".
 If you have from same column "SHOE INSIDE LENGTH" < measured length of your foot < "COMFORT SIZE" you will have the correct shoe size to order.

SHOES INSIDE LENGTH (CM)	25,8	26,7	27,5	28,4	29,2	30,1	30,9	31,8
SHOES INSIDE LENGTH (INCHES)	10,15	10,51	10,82	11,18	11,49	11,85	12,16	12,51
COMFORT SIZE (CM)	25	25,9	26,7	27,6	28,4	29,3	30,1	31,0
COMFORT SIZE (INCHES)	9,84	10,19	10,51	10,86	11,18	11,53	11,85	12,20
US SIZE	7	8	9	10	11	12	13	14
EUR SIZE	40,5	42	43	44,5	45,5	47	48	49,5
JPN SIZE	25,5	26,5	27,5	29,0	29,5	30,5	31,5	32,5

A. SHOES INSIDE LENGTH
 Example SIZE 9 (27,5 cm) / (10,82 inches)

B. COMFORT SIZE
 Example SIZE 9 (26,7 cm) / (10,51 inches)

